




DISASSEMBLY AND ASSEMBLY OF SUBASSEMBLIES


Gearshift Rail Bushing

Special Tool(s)

 <p>ST1144-A</p>	<p>Universal Puller Set 303-DS005 (D80L-100-A) or equivalent</p>
 <p>ST1085-B</p>	<p>Installer, Shift Rail Bushing 308-244 (T96P-7025-F)</p>
 <p>ST1185-A</p>	<p>Slide Hammer 100-001 (T50T-100-A)</p>

Disassembly and Assembly

- Using the special tools, remove the gearshift rail bearing from the transmission case. Discard the bearing.



- Using the special tool, install the main shift rail bearing.

