# DISASSEMBLY AND ASSEMBLY OF SUBASSEMBLIES

## Countershaft Bearing

### Special Tool(s)

| | |
|---|---|
| ST1895-A | Remover, Drive Pinion Bearing Cone<br>205-D002 (D79L-4621-A) or equivalent |

## Disassembly and Assembly

1. Cut the outer cage, then remove the outer cage and rollers.

2. Using the special tool and a press, remove the inner bearing.

3. Using the special tools, install the new countershaft bearing.

Copyright © 2004, Ford Motor Company